18KG WASHING MACHINE

1. Empty all pockets, load your landry and close the door properly.

2. Detergent will be dispensed automatically

3. Select the wash programme



1 - 2 - 3 (cycles avec prélavage)

4 - 5 (cycles sans prélavage)

4. At the payment terminal, select the machine, then its number

5. Select your payment method (cash or bank card)

6. If paying in cash, collect your change

7. On the machine, press start

Bulles de Garonne