DRYER

1 Load your laundry and make sure the door is properly closed.

⚠ **Do not put Rhovyl, wool or Damart garments in the dryer.**

2 Select the desired temperature:

3 At the payment station, select the dryer and then its number.

4 Select your payment method (cash or bank card).

5 If paying in cash, collect your change.

6 On the dryer, press START.

For best drying results, we recommend a minimum total drying time of 30 minutes.

Bulles de Garonne